# **Report Generated by Test Manager**

Title: Test

**Author:** 

Date: 09-Jan-2021 20:31:33

## **Test Environment**

Platform: PCWIN64 MATLAB: (R2020b)

## **Summary**

Name Outcome Duration (Seconds)

Results: 2021-Jan-09 20:30:44 4.023

■ AlertaTiempoSinAlimentar
 ■ 4.022

Results: 2021-Jan-09 20:30:44

Result Type: Result Set Parent: None

Start Time: 09-Jan-2021 20:30:46 End Time: 09-Jan-2021 20:30:50 Outcome: Total: 1, Failed: 1

**Back to Report Summary** 

## AlertaTiempoSinAlimentar

#### **Test Result Information**

Result Type: Test Case Result

Parent: Results: 2021-Jan-09 20:30:44

Start Time: 09-Jan-2021 20:30:46 End Time: 09-Jan-2021 20:30:50

Outcome: Failed

Cause of Failure: Failed criteria: Assessments

Description:

Testea que se envíe correctamente una alerta cuando se ha superado un tiempo determinado desde la última vez que se dispensó comida.

#### **Test Case Information**

Name: AlertaTiempoSinAlimentar

Type: Baseline Test

**Test Case Requirements** 

Description: RF-SY\_07 (Requisito cruzado): Aviso de emergencia. El gato

lleva demasiado tiempo sin alimentarse (gatera#21)

Document: ../resources/requirements/gatera.slreqx

### **Logical and Temporal Assessments**

Name	Assessment
Assessment1	At any point in time, whenever (tiempoSinAlimentar >= 25) is true then, with a delay of at most 5 seconds, (alertaDispensar == 1) must be true

Assessment2	At any point in time, if (autorizUsuarioCom == 1) becomes true then, with a delay of at mos t 30 seconds, ((alertaDispensar == 0) & (actComedero == 1)) must be true
Assessment3	At any point in time, if (propietarioDormido == 1) becomes true then, with a delay of at mo st 30 seconds, ((alertaDispensar == 0) & (actComedero == 1)) must be true
Assessment4	At any point in time, whenever ((alertaDispensar == 0) & (actComedero == 1)) is true then, with a delay of at most 11 seconds, (actComedero == 0) must be true

#### **Simulation**

#### **System Under Test Information**

Model: estados\_test

Harness: ALAlertaTiempoSinAlimentar

Harness Owner: estados\_test
Release: Current
Simulation Mode: normal

Override SIL or PIL 0

Mode:

Configuration Set: Configuration1

Start Time: 0 Stop Time: 150

Checksum: 2674434678 3059227133 3915565427 3384663654

Simulink Version: 10.2 Model Version: 1.18 Model Author: Iranzu

Date: Wed Jan 06 13:28:22 2021

User ID: Iranzu

Model Path: C:\Users\Iranzu\Documents\ESTUDIOS

IRANZU\UNIVERSIDAD\MASTER\UPM\SEGUNDO

CURSO\INGENIERÍA DE

SOFTWARE\TRABAJO\TESTING\MODELO\_FINAL\_ V5\CATSAFE\ALAlertaTiempoSinAlimentar.slx

Machine Name: LAPTOP-PRFJ9D0P Solver Name: VariableStepDiscrete

Solver Type: Variable-Step

Max Step Size: 3


Simulation Start Time: 2021-01-09 20:30:46 Simulation Stop Time: Platform: 2021-01-09 20:30:49

PCWIN64

**Simulation Output** 


Name	Data Type	Units	Sample Time	Interp	Sync	Link to Plo t
Input Conversion Su bsystem:16	double		Continuous	zoh	union	<u>Link</u>
Input Conversion Su bsystem:3	double		Continuous	zoh	union	<u>Link</u>
actComedero	double	 	Continuous	zoh	union	Link
tiempoDispensa	double	i 	Continuous	zoh	union	Link
alertaDispensar	double	i 	Continuous	zoh	union	Link
tiempoSinAlimentar	double		Continuous	zoh	union	<u>Link</u>

Name	Data Type	Units	Sample Time	Interp	Sync
Input Conversion Su bsystem:16	double		Continuous	zoh	union
Input Conversion Su bsystem:3	double		Continuous	zoh	union




Back to Report SummaryBack to Signal Summary

Name	Data Type	Units	Sample Time	Interp	Sync
actComedero	double		Continuous	zoh	union
tiempoDispensa	double	<del></del>	Continuous	zoh	union



Back to Report SummaryBack to Signal Summary

Name	Data Type	Units Sample Time		Interp	Sync
alertaDispensar	double	 	Continuous	zoh	union
tiempoSinAlimentar	double		Continuous	zoh	union



Back to Report SummaryBack to Signal Summary

## Simulation Logs:

'dispensaComida' is defined, but is not used in the Stateflow chart. <u>Delete this object or configure the diagnostic.</u>

'Output Port 18' of 'ALAlertaTiempoSinAlimentar/estados\_test' is not connected.

<u>'actGatera'</u> is defined, but is never used in the Test Sequence block. <u>Delete this object.</u>

<u>'actComedero'</u> is defined, but is never used in the Test Sequence block. <u>Delete this object.</u>

<u>'peticionUsuario'</u> is defined, but is never used in the Test Sequence block. <u>Delete this object.</u>

<u>'peticionIntHora'</u> is defined, but is never used in the Test Sequence block. <u>Delete this object.</u>

<u>'modoReal'</u> is defined, but is never used in the Test Sequence block. <u>Delete this object.</u>

<u>'ubicacion'</u> is defined, but is never used in the Test Sequence block. <u>Delete this object.</u>

<u>'gatoIntroducido'</u> is defined, but is never used in the Test Sequence block. <u>Delete this object.</u>

<u>'camarasOUT'</u> is defined, but is never used in the Test Sequence block. <u>Delete this object.</u>

<u>'camarasIN'</u> is defined, but is never used in the Test Sequence block. <u>Delete this</u> object.

<u>'tiempoSalida'</u> is defined, but is never used in the Test Sequence block. <u>Delete this object.</u>

<u>'alertaTiempoFuera'</u> is defined, but is never used in the Test Sequence block. <u>Delete this object.</u>

<u>'tiempoFuera'</u> is defined, but is never used in the Test Sequence block. <u>Delete this object.</u>

<u>'tiempoDispensa'</u> is defined, but is never used in the Test Sequence block. <u>Delete this object.</u>

<u>'alertaDispensar'</u> is defined, but is never used in the Test Sequence block. <u>Delete this object.</u>

<u>'tiempoSinAlimentar'</u> is defined, but is never used in the Test Sequence block. <u>Delete this object.</u>

<u>'alertaLluvia'</u> is defined, but is never used in the Test Sequence block. <u>Delete this object.</u>

<u>'modoAnt'</u> is defined, but is never used in the Test Sequence block. <u>Delete this object.</u>

**Back to Report Summary** 

Test Logs:

No baseline	criteria	evaluation	performed	as no	baseline	data is	available	for
this test.			-					

Back to Report Summary